







EyeSystems Preliminary Adjustments • Eyewire and wrap
























































EyeSystems
Adjusting Nose Pads

Nose pad angles
Frontal angle
Splay angle

• Vertical angle





## \_\_\_\_\_ EyeSystems

## Adjusting Nose Pads

- Pads should
  - Rest halfway between the crest of the nose and the inner canthus.
  - Be flush with the surface.
  - Be adjusted to increase or decrease vertex distance.



28





